

isai vivid LGV32

Basic Manual

For detailed operation methods, refer to "Basic Manual" application installed on the product.

September 2015, 2nd Edition
MPL69165002(1.1)

For inquiries, call:


Customer Service Center
For general, charge, operations (toll free)
Business hours 9:00 ~ 20:00 (7 days a week)From fixed-line phones:
#0077-7-111 From au cell phones:
157 area code not required
PRESSING ZERO WILL CONNECT YOU TO AN OPERATOR
AFTER CALLING 157 ON YOUR AU CELL PHONEFor service canceling procedure in case of loss or theft (toll free)
Business hours 24-hour (7 days a week)
From fixed-line phones:
#0077-7-113 From au cell phones:
113 area code not requiredIn case above numbers are not available:
#0120-977-033 (except Okinawa)
#0120-977-699 (Okinawa)Keitai Guarantee Service Center
For loss, theft or damage (toll free)
Business hours 9:00 ~ 21:00 (7 days a week)
From fixed-line phones/au cell phones:
#0120-925-919Cell phone and PHS operators collect and
recycle unused telephones, batteries and
battery chargers at stores bearing the logo regardless of brand and manufacturer
to protect the environment and reuse
valuable resources.やめましょう、
歩きスマホ。
△ キケン！
水ぬれ充電Sold by: KDDI CORPORATION,
OKINAWA CELLULAR TELEPHONE COMPANY
Imported by: LG Electronics Japan Inc.
Manufactured by: LG Electronics Inc.

- Tsunami Warning is a notification delivered from the meteorological bureau (major tidal wave, seismic sea wave) to the area including target coast.
- Disaster and Evacuation Information is a service that distributes bulletins concerning residents' safety including evacuation advisories, evacuation orders and other warnings issued by the national and local governments.
- The service is available only in Japan (it cannot be used overseas).
- No information fee or communication charge is required for receiving Emergency Rapid Mail.
- KDDI is not liable for damages suffered by customers resulting from the service's information, lack or delay in the information caused by transmission or system breakdowns, or other events that are outside the responsibility of KDDI.
- Refer to the Japan Meteorological Agency web page for details about distribution of Earthquake Early Warning.
<http://www.jma.go.jp/>
- You cannot receive any Emergency Rapid Mail if the product is turned off.

- 13 -

Removing Battery Pack

- 1 Remove the back cover
- 2 Insert your fingernail in the recess of the unit, and while pushing the battery pack in the direction of the arrow (1), lift it in the direction of the arrow (2)




3 Attach the back cover

- 14 -

au Nano IC Card 04

au Nano IC Card 04 stores your personal information such as a phone number.



Note the following points, which may cause malfunction or damage, when handling the au Nano IC Card 04.

- Do not touch the IC (metal) part of the au Nano IC Card 04 or the IC card terminal inside the product.
- Insert the au Nano IC Card 04 in the correct orientation.
- Do not use force to attach or remove the IC card.
- Do not lose the au Nano IC Card 04 after it has been removed.
- Before attaching/removing au Nano IC Card 04, be sure to remove the microUSB connector of specified AC adapter (sold separately) etc. from the product.

- 20 -

- 21 -

- 22 -

- 23 -

- 24 -

- 25 -

- 26 -

Preface

Thank you for purchasing the "isai vivid (LGV32)" (simply called the "product" from here on). Before using the product, be sure to read the "Setting Guide", "Notes on Usage", "Basic Manual" (this manual) or "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) available on the au homepage to ensure correct use. After you have finished reading this PDF and the printed manuals, be sure to store them in safe places so that you can retrieve them whenever needed.

List of Packaged Items

Before you start using the product, make sure that you have all of the following packaged with the product.

- Main unit (including back cover)
- Battery pack (LGV32UAA)



- 1 -

LG TV antenna cable 01



● 設定ガイド (Setting Guide) (Japanese)
● ご利用にあたっての注意事項 (Notes on Usage) (Japanese)
● 取扱説明書 (Basic Manual) (Japanese)
● 保証書 (Warranty) (Japanese)

The following items are not included in the package.

- microUSB cable
- microSD memory card
- Earphone
- AC adapter
- Desktop holder

- Purchase a specified charger (sold separately).
- The illustrations of the cell phone in the manual are used only for explaining. They may differ from the actual product.
- When watching TV, connect the antenna cable. For details on connecting, refer to "TV antenna cable".

About Operating Instructions

Basic Manual (this manual)

Handles only basic operations for main features. For detailed descriptions on various functions, refer to the "Basic Manual" application installed on the product or "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) available on the au homepage. <http://www.au.kddi.com/support/mobile/guide/manual/>

• All company names and product names in this manual are either trade marks or registered trade marks.

Basic Manual application

You can use the "Basic Manual" application on the product to confirm detailed operational procedures. Certain functions can be directly activated from the application screens on which their operations are described.

Operation procedures

- 1 On the home screen ▶ ▶ Slide the browser screen page down
- 2 ▶ "isai vivid サポート情報 (isai vivid support information)"
- 3 From a computer or smartphone <http://www.au.kddi.com/support/mobile/guide/mobile/lvg32/index.html?bid=cs-cs-mobile0002>

- 2 -

Downloading Manuals

You can download the "Basic Manual" (this PDF manual), the "Setting Guide", the "Notes on Usage" and "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese) in PDF format from the au homepage. Download URL: <http://www.au.kddi.com/support/mobile/guide/manual/>

Support information

You can view videos and images describing basic operations and recommended functions as well as instruction manuals, update information, and other support information.

Operation procedures


- 1 On the home screen ▶ ▶ "サポート (Support)" ▶ "Basic Manual"

- When you activate for the first time, follow the onscreen instructions to download and install the application.

- 3 -

Regarding Notations Used in This Manual

■ Key indications used in this manual
In this manual, keys are represented by simplified illustrations as shown below.



Indications used for the operation of selecting items/icons/buttons, etc.

The notations used for operation procedures in this manual are as follows.
Tap means to lightly touch and release the button or icon shown on the display to select it.

Description	Explanation
On the home screen ▶ ▶ "1" "4" "1"	Tap "1" (Phone) on the bottom of the home screen. Tap "1" "4" "1" "1" and "4".

- 5 -

Description

On the home screen On the bottom of the home screen, tap "□".

- This manual uses screenshots and describes operations with the au Nano IC Card 04 inserted.
- Descriptions in this manual are based on the operations of portrait screen. Items, icons, or the keys on the screen may look different with landscape screen.
- Items, title levels, and icons in this manual may look different based on different functions you use or different conditions, etc.
- In this manual, "microSD™ memory card", "microSDHC™ memory card" or "microSDXC™ memory card" is called "microSD memory card" or "microSD" for short.
- All of the indicated amounts exclude tax unless otherwise specified.

Illustrations and screen displays used in this manual

Illustrations and screens shown in this manual may look different from the actual product or screen. In some cases, minor details or a part of a screen may be omitted.

- 6 -


Emergency Rapid Mail is a service that distributes Earthquake Early Warning or Tsunami Warning delivered from the meteorological bureau or Disaster and Evacuation Information delivered from the government or local public organization to all au cell phones in specified areas simultaneously.

- Reception of Earthquake Early Warning is notified by a special warning tone, voice ("地震です"Jishindesu") (An earthquake) and vibration.
- When you receive Emergency Rapid Mail during a call, the warning tone does not sound.
- Earthquake Early Warning is sent to areas where strong quakes (over 4 degrees) are expected when the earthquake whose maximum seismic intensity 5 lower is anticipated occurs.

- Immediately after an earthquake occurs, quakes (P waves and initial tremors) near the epicenter are detected and position, scale, and expected strength are automatically calculated and notification is sent as soon as possible within a few seconds to tens of seconds before the strong quakes (S waves and major tremors) caused by the earthquake start.
- Earthquake Early Warning may not arrive before strong tremors in arrears near the epicenter.

- 12 -

- To maintain waterproof performance, securely close the cover to make sure that the cover is not partially open.



Attaching/Removing Battery Pack

- 1 Place the face of the battery pack with the au logo upwards, align the product connector with the battery pack terminal, and insert the battery pack in the direction of the arrow (1)



△ : There is no tab here on the back cover (Leather black, Leather brown).

Attaching Battery Pack


- 1 Hook the groove of the back cover with your fingernail, then lift it from the bottom in the direction of the arrow to remove it
- 2 Place the face of the battery pack with the au logo upwards, align the product connector with the battery pack terminal, and insert the battery pack in the direction of the arrow (1)



Removing au Nano IC Card 04

Before removing the au Nano IC Card 04, first turn off this product, and remove the back cover and battery pack.

- 1 Remove the back cover
- 2 Remove the battery pack
- 3 Insert your fingernail into the groove at the back of the au Nano IC Card 04 slot and push the au Nano IC Card 04 in the direction of the arrow (1)
- 4 Gently pull out the au Nano IC Card 04 in a straight line (2)




- 17 -

Charging

When you purchase your cell phone, the battery pack is not fully charged. Charge the battery pack when you use it for the first time or when its battery is not enough.

- While charging, the product and its battery pack might become hot. It is not abnormal. (When activating camera or communicating data while charging, the battery pack becomes hot.)



Charging with the Specified AC Adapter (Sold Separately)

Describe how to charge by using the common AC adapter 05 (sold separately).

For details on the specified AC adapter (sold separately), refer to "Introduction of Related Accessories".

- 25 -

- 26 -

3 When charging is completed, remove the microUSB connector of the common AC adapter 05 (sold separately) straight from the external connection terminal of the product
4 Remove the power plug of the common AC adapter 05 (sold separately) from power outlet


memo
When 1 is not displayed
• Wait until 1 is displayed on the status bar of the top screen. Bad connection is assumed if it does not appear after a while. Check if Common AC Adapter 05 (sold separately) is securely connected. If it still does not appear, stop charging and contact an au shop or a Keitai Guarantee Service Center.

Charging with a PC

1 Insert the microUSB connector of the microUSB cable (sold separately) directly into the external connection terminal of the product
• Insert the microUSB connector straight with the "B" mark facing up.

- 27 -

2 Insert the microUSB connector of the microUSB cable (sold separately) straight into the USB port of the PC



memo
• Although charging with the power of the product on is available, it takes longer.
• It may take longer to charge with USB than the specified AC adapter (sold separately).
• When the "Start new hardware search wizard" window appears, select "Cancel".

- 28 -

Turning the Power On/Off

Turning the Power On

1 Power key (Press and hold for more than 2 seconds)
The lock screen appears.
Swipe the screen to unlock.
2 Turning the Power Off


1 Power key (Press and hold for more than 2 seconds)
2 "Power off" ▶ "OK"

- 29 -

Checking The Product State

Understanding Icons

Notification icons such as a missed call, new mail, or other operations in use are displayed on the left side of status bar. On the right side, status icons showing the state of the product are displayed. Also slide the status bar downwards to display the notification panel.




Major notification icons

Icon	Description
Missed call	New mail message (E-mail)
New mail message (PC mail)	New mail message (Gmail)
New SMS message	Display notification for Address Book Plus setting
Receiving a call	Displayed during a high quality call from an au cell phone that supports VoLTE

- 36 -

Lock screen

The Lock screen is displayed when the power is turned on or after sleep mode has been deactivated. On the Lock screen, you can check the date and time, and notification information as well as use application shortcuts.



Unlocking the Lock screen


1 Swipe the Lock screen
The home screen appears.
• The unlock method differs depending on the screen lock settings.

- 30 -

Using the Home Screen

Viewing Home Screen

The home screen is configured of multiple desktops, and desktops can be switched by sliding/flicking to the right and left. Shortcuts, widgets, and folders can be added by adding a desktop.



- 31 -

Using the Home Screen

○ Home key
Displays home screen.
□ Task key
Displays a list of active applications. Touch and hold to configure settings.

memo

• When you tap an icon to use its functions, communication fee may be charged depending on the function.

Using the Home Screen

Changing Desktop

Desktops can be switched by sliding/flicking to left or right.



memo
• Thumbnails can be displayed by pinching in on the home screen to add/delete desktop, change order, etc.


- 32 -

LED Notification

LED notification informs charging prompt, battery level while charging, missed calls, etc. by lighting on or flashing.

LED color and movement

LED color and movement	Description
Flashing red	Indicates that it is charging.
Flashing green	Indicates incoming call, missed call, notification message.
Lighting green	Indicates that charging is complete.
Flashing rainbow	Indicates that an alarm is sounding.



Checking Your Phone Number

1 On the home screen ▶ Touch and hold "□" ▶ "System settings" ▶ "General" tab ▶ "About phone" ▶ "Status"
Status screen appears and your phone number is shown in My phone number field

memo

• For details on making/receiving a call, refer to "Setting Guide".

Setting Silent Mode

Set Silent mode (Sound profile) not to inconvenience people around you in a public place.

1 Open the Notifications panel ▶ "Sound"/"Vibrate"

Setting Airplane Mode

When Airplane mode is set, wireless functions are disabled (telephone, packet transmission, wireless LAN (Wi-Fi®), Bluetooth®).

1 Power key (Press and hold for more than 2 seconds) ▶ "Turn on Airplane mode" ▶ "OK"

Entering Text

Use the software keyboard to enter characters. To display the software keyboard, tap a character input box in the character input screen when adding contacts, creating a message, etc.

- 40 -

Switching the Software Keyboard

1 Character input screen ▶ Touch and hold "□" ▶ "Add apps & widgets"

2 Tap an item shown below


Icon	Description
Apps	Create a shortcut of an application.
Widgets	You can add widgets such as calendar, music, etc. You can add shortcut of settings menu also.
Wallpapers	Select from Gallery, Multi-photo, Live wallpapers, Photos, etc.
3 Drag to the area to add shortcuts/widgets	
■ Adding a folder	
1 Touch and hold app/shortcut to store into a folder	
2 Drag onto another app/shortcut and release your finger	App/shortcut is stored into the folder.

- 34 -

Using a microSD Memory Card

Installing a microSD Memory Card

1 Remove the back cover
2 Remove the battery pack
3 Place the face of the microSD memory card with the logo upwards and insert all the way into the microSD memory card slot in the direction of the arrow



memo
• Make sure that the top and bottom of the microSD memory card are facing correctly.
• Trying to force a wrongly oriented card into the slot could make it impossible to remove the card and result in damage.

Removing a microSD Memory Card

1 On the home screen ▶ Touch and hold "□" ▶ "System settings" ▶ "General" tab ▶ "Storage" ▶ "Unmount SD card"
2 Remove the back cover
3 Remove the battery pack
4 Gently pull out the microSD memory card
Gently and straightly pull it out.

- 35 -

Viewing the Setting Menu

1 On the home screen ▶ Touch and hold "□" ▶ "System settings"

2 Setting menu item list

Networks tab
Make communication settings such as Wi-Fi®, Bluetooth®, call settings.

Sound & notification tab
Configure sound and vibration for the ringtone and music playback as well as notification settings.

Display tab
Make settings of home screen, lock screen, display brightness, etc.

General tab
Set security, add/delete accounts for online services, set such as backup and reset, check about phone, etc.

- 37 -

Introduction of Related Accessories

■ Battery pack (LGV32UAA)
■ Back cover (LGV32TNA/LGV32TWA/LGV32TKA/LGV32TFA/LGV32TTA)
■ LG TV antenna cable 01 (01LGHSA)
■ au Carrying Case G Black (0106FCA) (sold separately)
■ AC Adapter (sold separately)

• Common AC adapter 03 (0301PQA)
• Common AC adapter 03 Navy (0301PBA)
• Common AC adapter 03 Green (0301PGA)
• Common AC adapter 03 Pink (0301PPA)
• Common AC adapter 03 Blue (0301PLA)
• Common AC adapter 05 (0501PWA)
• AC Adapter JUPITRIS (White) (L02P001W)
• AC Adapter JUPITRIS (Red) (L02P001R)
• AC Adapter JUPITRIS (Blue) (L02P001L)
• AC Adapter JUPITRIS (Pink) (L02P001P)
• AC Adapter JUPITRIS (Champagne Gold) (L02P001N)
■ Common DC adapter 03 (0301PEA) (sold separately)

memo
• The Portable Charger 02 (sold separately) may not be able to sufficiently charge the product.

• For the latest information on accessories, visit the au homepage (<http://www.au.kddi.com/>) or contact the Customer Service Center.

• This product does not support ASYNC/Fax transmission.

• You can purchase accessories on this page from au online shop.

Some accessories may not be purchased due to the availability.

<http://auonlineshop.kddi.com/>

- 38 -

Downloading and Updating Software

1 On the home screen ▶ Touch and hold "□" ▶ "System settings" ▶ "General" tab ▶ "About phone" ▶ "Update Center" ▶ "Software Update"

When you use the product for the first time, a screen confirming software updates appears. Check the content and tap "AGREE".

2 "Check now for update"

Check if there is new software.

Software update screen is displayed when software updates available.

3 "Select a communication method to download software"

Select a communication method to download software.

4 "DOWNLOAD"

A new software download starts.

5 "INSTALL NOW"

Software update starts.

The product will restart a couple of times during the software update.

6 "OK"

You are recommended to back up your data before updating software.

• If software update has failed or stopped, update the software again.

• Update is unavailable during international roaming.

Do not conduct the following operations during software update.

• Do not move this product during software update.

• Operations are not available during software update.

• Calls to 110 (Police), 119 (Fire department or ambulance service), 118 (Japan Coast Guard) and 157 (Customer Service Center) are also not available.

• Make sure to charge your phone before software update. If battery is not enough, software update may fail.

• Check out the signal reception. Software update may fail if you are at a place with bad signal reception.

• Data registered on the product (Contacts, mail, still images, music, etc.) and setting information will not be changed even after software is updated.

• However, note that data might not be protected depending on the state of the product (malfunction, damage, getting wet, etc.).

When software update is not available, etc.

• If you fail to update software, it may become impossible to operate the product. In that case, bring the product to an au shop or PiPit (not accepted by some shops).

You are recommended to back up your data before updating software.

• If software update has failed or stopped, update the software again.

• Update is unavailable during international roaming.

Do not conduct the following operations during software update.

• Do not move this product during software update.

• Operations are not available during software update.

• Calls to

If this unit is machined, analyzed (including software modifications and analysis (including rooting) reverse engineering, decompiling, and reverse assembling) or is repaired by a repair facility that is not an au-specified official repair facility may not be covered by warranty or eligible for repair.

Keitai Guarantee Service Plus LTE
An after-sales service membership program on a monthly basis called "Keitai Guarantee Service Plus LTE" (monthly fee: 380 yen, tax excluded) is available for using your au cell phone for a long time without worries. This service expands coverage for many troubles including malfunction, theft and loss. For details of this service, refer to au homepage or contact a Keitai Guarantee Service Center.

au Nano IC Card 04
The au Nano IC Card 04 is lent to you by au. In case of loss or damage, the card will be replaced at your expense. When a malfunction is suspected, or in case of theft or loss, contact an au shop or PiPit.

After-sales Service
If you are unsure about anything regarding after-sales service, contact the following service contact. Customer Service Center (for service canceling procedure in case of loss or theft)
From a land-line phone: **0120-925-919** (toll-free)
From an au mobile phone: **113** without area code (toll-free)
Business hours 24-hour (7 days a week)

Keitai Guarantee Service Plus (for loss, theft, damage)

From a land-line phone/From an au cell phone,

0120-925-919 (toll free)

Business hours 9:00 ~ 9:00 PM (7 days a week)

Repair service from online (24 hours a day over the Internet)

*

Reception only from PC or smartphone

https://cs.kddi.com/support/n_login.html

• The Application for the Internet acceptance, if "damage", "wet", "theft" and "loss" are eligible. In the case of spontaneous failure (not the cause damage, such as water wet, but does not power on, the screen does not function or other), it will be accepted by phone for interview is required.

• To apply for the Internet, you need the e-mail address.

au after-sales service information

Service Contents

Keitai Guarantee Service Plus LTE

Member Nonmember

Holding over and repair

Spontaneous failure

1st year

2nd year or later

Customer charge

1st: 5,000 yen

2nd: 8,000 yen

Actual cost

Partial damage, water stained, irreparable damage, theft, or loss

Customer charge

Upper limit: 5,000 yen

Water stained, irreparable damage

Customer charge

10,000 yen

Theft, loss

N/A

(model change)

Keitai Guarantee Service Plus LTE

Member Nonmember

Holding over and repair

Spontaneous failure

1st year

2nd year or later

Customer charge

(3-year warranty)

Actual cost

memo
Replacement cell phone delivery service
• When you have trouble with your au cell phone, a replacement cell phone (same model, same color, including new battery) is delivered to the specified place by calling to. Return your damaged cell phone within 14 days after the replacement cell phone is delivered.
• Available up to twice in a year from the day you use this service as a start day. If you do not use this service in the past year for the subscription to this service, it will be 1st time and if you use, it will be the 2nd.
* For details, refer to au homepage.
Holding over and repair
• Damages and malfunctions intentionally caused by the customer as well as those due to modification (e.g. disassembly, change of parts, painting, etc.) by the customer are not covered by this service.
• You cannot receive a refund for the replacement of the outer casing due to stains, scratches, paint removal, etc. on the outer casing.

*Charge amounts are all tax excluded.

- 55 -

- 56 -

- 57 -

- 58 -

- 59 -

- 60 -

- 61 -

Unlocking the SIM lock

You can unlock the SIM lock for this product. If you unlock the SIM lock, you can use other carrier's SIM cards.


- The au homepage and au shops are accepting requests to unlock the SIM lock.
- If you use another carrier's SIM card, some services and functions may be restricted. Note that au does not guarantee any operations.
- To unlock the SIM lock, go to home screen ▶ Touch and hold □ ▶ "System settings" ▶ "General" tab ▶ "About phone" ▶ "SIM card".
- For more details, refer to the au homepage.

TV Antenna Cable

When watching TV, connect the supplied LG TV antenna cable 01 to the product. Also, connect the commercial earphone to the LG TV antenna cable 01 to listen to the TV's audio.

The connection procedures for the LG TV antenna cable 01 are described here.

- Insert the commercial earphone plug into the LG TV antenna cable 01 earphone jack
- Insert the LG TV antenna cable 01 connection plug into this product's earphone jack



- 62 -

- 63 -

- 64 -

- 65 -

- 66 -

Main Specifications

Display	Approx. 5.5 inches, Approx. 16.77 million colors, AH-IPS liquid crystal 2560 x 1440 dots (WQHD)
Weight	Approx. 150 g (including battery pack) ¹ / Approx. 151 g (including battery pack) ²
Size (W x H x D)	Approx. 76 mm x 150 mm x 10.3 mm (thickest part 11.3 mm) ¹ / Approx. 76 mm x 150 mm x 10.5 mm (thickest part 11.3 mm) ²
CPU	MSM8992(1.8 GHz x 2 ea) +(1.4 GHz x 4 ea)
Memory (Internal)	ROM : 32 GB, RAM : 3 GB
Continuous calling time	In Japan Approx. 1,300 minutes Overseas Approx. 870 minutes
Continuous standby time ³	In Japan Approx. 380 hours Overseas (GSM) Approx. 400 hours

Continuous tethering time

Number of concurrent connections with tethering	13 devices (Wi-Fi® tethering: 8, Bluetooth® tethering: 4 and USB tethering: 1)
Charging time	AC adapter Approx. 110 minutes (When using Common AC adapter O5 (sold separately)) DC adapter Approx. 630 minutes (When using Common DC adapter O3 (sold separately))
Continuous watching time ⁴	Full Seg Approx. 5 hours 10 minutes 1Seg Approx. 5 hours 50 minutes

*1 When the back cover is mounted (White, Champagne, Black).

*2 When the back cover is mounted (Leather black, Leather brown).

*3 Continuous standby times are measurements in a static state.

*4 Continuous viewing time may change depending on the usage condition.

memo

The continuous talk time and continuous standby time may drop to less than half depending on the battery charging status, usage environment such as temperature, reception condition at the location where the product is used, and the function settings.